




9BB12

CV Boot Clamp Pliers

- Use to remove and install stainless CV boot clamp
- Can be used with 1/2" flexible handle bar or torque wrench
- Suitable for Audi, Opel, Citroen, SEAT, BMW, Mercedes-Benz, Honda, Nissan, Mazda, Ford, GM, Chrysler



Item	L		A Max(mm)		
	(mm)	(inch)			
9BB12	235	9-1/2	12	512.4	6 / 36