



9DA103



1/2" DR. Spline Bit Socket-M10

- Specialized in removing & installing freewheel pulleys on alternator.
- Ideal for dismantling and assembling the free wheel pulley while changing the alternator or pulley.
- The pulley shaft is held in place with the bit on 1/2" DR. socket whilst the nut is undone using the 33 teeth union nut with 19mm spanner
- Suitable generator brand: Bosch, Valeo, Magetic Marelli, Denso, etc.
- It's also interchangeable and comprehensive components to work on VW, Audi, Citroen/ Peugeot, Mercedes, Renault, BMW, Flat, Ford, Toyota, etc



Item	 No.	Overall Length mm	 g	
9DA103	M10	113	151	10 / 120