



9BK11



轮胎铅子钳

— 用于钢圈轮胎平衡铅块的安装与拆除



Item	L		A B			
	(mm)	(inch)	(mm)	(mm)		
9BK11	250	10	22	86	420	10 / 50