

CORDLESS BUTANE GAS GLUE GUN OPERATION MANUAL




NO.6BJ21

Please wear proper safety gear while working.



CORDLESS BUTANE GAS GLUE GUN

- Self-regulating temperature system that prevents glue from coming out and getting stuck in the nozzle or dripping everywhere
- Fast-heating in 2 to 3 minutes
- Quick and easy to refill gas. It only takes 3 seconds which lasts for approximately 1.5 hours
- Front top heater design for safe usage
- Portable and cordless for convenient application
- Passed the 250 hour continuous work durability test
- Includes 2PC. 11mm glue stick
- Suitable for wood working, household repairs, artificial flowers, models, art and decorations etc...
- Optional glue stick 6BJ901. Packed by 10pcs
- Comfortable ergonomic grip



1. Refilling gas



3. Press the ignition button and wait 2-3 min (Make sure the indicator on)



2. Turn the gas switch on



4. Automatic temperature control turns off at 180° and turns on under 160°

IDEAL USE FOR:

- Furniture
- Woodworking
- Household use
- Flooring and baseboards
- Artificial flowers
- Toys and models
- Art and decorations

No.6BJ21		No.6BJ901	
Gas capacity (ml)	6.8	Gas capacity (ml)	-
Operation time (min)	90	Operation time (min)	-
Glue size (mm)	11	Glue size (mm)	11
Gas type	Butane	Gas type	-
Heat temp °C	160-180	Heat temp °C	-
Dimension L x W x H (mm)	174.8x39.4x153.7	Dimension L x W x H (mm)	Ø11 x 150mm



1	Air hole
2	Glue nozzle
3	Display dot
4	Stick trigger
5	Glue stick entry
6	Gas controller:ON/OFF
7	Gas tank
8	Gas refilling valve


WARNING :

- Don't touch the nozzle when it is used with high temp.
- Read the instructions carefully before using the appliance.
- Butane is very flammable, handle with care.
- Don't damage the air inlet with metallic or pointed objects.
- Before putting the appliance down or back into its box, make sure the unit is turned off.
- Don't immerse hot parts in water; let them cool down naturally.
- Disassembling, modifying the appliance or adding spare parts that are not provided by the manufacturer may be hazardous and is strictly forbidden.
- Suggested to be used with pure butane lighter gas.
- Use only in a well-ventilated space.
- Keep the appliance out of reach of children.
- While refilling with gas, the refilling volume can vary based on different gas pressure. It won't impact to the operation of the unit.
- Do not modify the appliance.

Do not use the appliance if it has damaged or worn seals. Do not use an appliance that is leaking, damaged or isn't operating properly.

If there is a leak in your appliance (smell of gas), take it outside immediately into a well ventilated flame-free location where the leak may be detected and stopped. If you wish to check for leaks on your appliance, do it outside.

Do not try to detect leaks using a flame, use soapy water.



INDEX NO.	KT NO.	DESCRIPTION	REQ'D NO.
1	6BJ21-A01	Heat pipe set	1
2	6BJ21-A02	Spring	1
3	6BJ21-A03	Metal net	1
4	6BJ21-A04	Metal tube	2
5	6BJ21-A05	Connector	1
6	6BJ21-A06	Orifice set	1
7	6BJ21-A07	Metal ring	1
8	6BJ21-A08	Protector	1
9	6BJ21-A09	Spring	1
10	6BJ21-A10	ON/OFF Switch device	1
11	6BJ21-A11	Ingas set	1
12	6BJ21-A12	Rubber ring	1
13	6BJ21-A13	Spring	1
14	6BJ21-A14	Trigger set	1
15	6BJ21-A15	Protector	1
16	6BJ21-A16	Piezo	1
17	6BJ21-A17	Button	1
18	6BJ21-A18	Isolation plate	1
19	6BJ21-A19	Cover	1
20	6BJ21-A20	Conductor	1
21	6BJ21-A21	Right plastic cover	1
22	6BJ21-A22	Left plastic cover	1
23	6BJ21-A23	Screw	1
24	06BJ21-A24	Screw	7
25	06BJ21-A25	Stand	1

20220301R1

