


Ball Joint Extractor

9BE4

- For quick and easy separation of ball joint pivots of pitman arms, steering tie rods, ball joints, etc
- Suitable for general trucks and vehicles
- For better safe operation & avoid damage



KT NO.	A mm	B mm	C mm	D mm		
9BE41	36	40	18	17	363.9	1 / 36
9BE42	46	48	23	17	558.3	1 / 36
9BE43	62	62	29	19	925.0	1 / 12
9BE44	64	76	40	24	1658.3	1 / 12
9BE45	77	100	46	24	1858.3	1 / 12



Inner Tie Rod Tool

9BE52

- Remove and replace the axial joint
- Hex part on the end of tool: work with 27 mm wrench or 1/2" DR. ratchet

KT NO.	L inch	L mm	Ø Capacity mm		
9BE52	15-3/4	400	35~45	2.14	1 / 10



Multi-Purpose Inner Tie Rod Tool

9BE62

9BE63

- Use for replace inner tie rod ends without removing the rack and pinion
- Internal serrated design to make grip tight
- Use with ratchets and extensions by 1/2" sq drive
- Suitable for most vehicles & trucks



KT NO.	L inch	L mm	Ø Capacity mm		
9BE62	3-1/4	81.50	33~42	370.2	20
9BE63	3-7/16	87.56	42~50	403.6	20

