


Broken Screw Extractor & Drill Set

11225SQ

25
PC.

- Easy to remove 5~14 mm broken screws
- 15 PC. HSS drill bit & center guide
- 10 PC. extractor pin & nut

kg 0.79 1 / 20



Blow case size (mm) :
260 x 175 x 60 (0.096CUFT)

- Use the guide to drill a pilot hole in the center of broken screw
- Put on extractor nut turning out broken screw with wrench

Nut Splitter Set

9TD062

- For removing stubborn nuts or over tightened bolts without damaging the bolt thread
- Suitable for nuts to a tensile class 6
- Do not overtighten to prevent damage to the threads under the nut

kg 0.61 12 / 36

KT NO.	Capacity		Hex (mm)
	inch	mm	
9TD602	1/2"~5/8"	12~16	14
9TD603	5/8"~7/8"	16~22	19



2
PC.

9TD064

- Blow case size (mm) :
- 260 x 175 x 60 (0.096CUFT)

kg 1.89 1 / 12

KT NO.	Capacity		Hex (mm)
	inch	mm	
9TD601	5/16"~1/2"	9~12	12
9TD602	1/2"~5/8"	12~16	14
9TD603	5/8"~7/8"	16~22	19
9TD604	7/8"~1-1/8"	22~27	21



4
PC.

Stud Remover Tool

9TD404-0619M

1/2"

- Stud range: 6-19mm (1/4" - 3/4")
- Allows for easy removal of studs. Turn extractor with a ratchet, wrench or socket to engage the cam and stud, then pull out stud

kg 0.64 1 / 24

