

## Fuel Gauge & Pump Sender Collar Wrench

### 9AG11

- Use for removing and fitting fuel gauge sender collars to avoid damage
- 3 jaws to ensure high torque and no risk to damage plastic collar
- Use with 19mm wrench or socket
- Suitable for most collars from 89 to 170mm




KT NO.	Ø mm	kg	1 / 12
9AG11	89~170	1.05	1 / 12

## Adjustable Fuel Tank Lid Remover


### 9AG13

- Use for removing and fitting fuel gauge sender collars to avoid damage
- Special jaws design, no risk to damage plastic collar
- Use with 3/8" DR.
- Suitable for collars from 55 ~ 199mm
- Universal for application on most


560 1 / 24



BMW



BENZ



VW . AUDI  
BENZ . BMW



## Diesel Injector Extractor Tool

### 9AN021

- Use to remove injectors without dismantling the engine
- Suitable for Bosch injectors in Mercedes-Benz CDI engines 2.1 L and 2.2 L
- Application : Benz for Vito, Sprinter, Viano, C class, E class, CLC, CLK

2 1 / 6



## 6 in 1 Flywheel Puller

### 9XAH1

- This tool is designed to offer 6 different sizes for the Flywheel wheel rings on motorcycles
- Sizes include: M20 x 1.5R / M14 x 1.5R / M16 x 1.5R / M18 x 1.5R / M24 x 1.0R / M27 x 1.0L

730 1 / 24

