

9AG11

Fuel Gauge & Pump Sender Collar Wrench

- Use for removing and fitting fuel gauge sender collars to avoid damage
- 3 jaws to ensure high torque and without risk of destroy plastic collar
- Use with 19mm wrench or socket
- Suitable for most collars from 89 to 170mm





Item	Ø mm	Kg	
9AG11	89~170	1.05	1 / 12