Inner Tie Rod Tool

9BE52

- Removes and replaces the axial joint
- Hex part on the end of tool: works with 27 mm wrench or 1/2" DR. ratchet

KT NO.	L inch	L mm	Ø Capacity mm	kg	
9BE52	15-3/4	400	35~45	2.14	1 / 10





Multi-Purpose Inner Tie Rod Tool

9BE62 9BE63

- Use for replace inner tie rod ends without removing the rack and pinion
- Internal serrated design to make grip tight
- Use with ratchets and extensions by 1/2" sq drive
- Suitable for most vehicles & trucks







KT NO.	L inch	L mm	Ø Capacity mm	kg	
9BE62	3-1/4	81.50	33~42	370.2	20
9BE63	3-7/16	87.56	42~50	403.6	20

Universal Adjustable Wheel Bearing Lock Nut Wrench

9HBN01

- For disassemble and assemble vario nut and cap
- Extra slim design suitable to reach narrow space for special nut
- Use with 3/4" square drive tools and suggest to lock by torque wrench
- Application for 6PT, 8PT and round nut
- Adjustable open jaw 50~150mm

Contents:
3 pairs round adapter for round nut: 6mm, 8mm ,10mm
3 pairs square adapter for round nut: 1/4", 5/16", 3/8"

3.68 1 / 5

